REVISION					
LETTER	DFTSMAN	DATE	DESCRIPTION	APPROVED	DATE
Α	DNN	5/21/98	ADDED 41228-303-001 TO -001 & -002 LIST.		
В	DNN	10/22/03	ADDED -006 & -007 LISTS.	MARWILL	8/3/05

THE FOLLOWING LIST OF DRAWINGS ARE REQUIRED TO INSTALL THE ERA EXTERNAL AUXILIARY FUEL SYSTEM ON THE BELL HELICOPTER MODELS NOTED BELOW:

41228-000-002-001	Auxiliary Fuel System Instl. For Bell Model 412 (S/N 33001-33107) with Single Refueling Port Provisions
41228-000-002-002	Auxiliary Fuel System Instl. For Bell Model 412 (S/N 33108 & Sub.) with Single Refueling Port Provisions
41228-000-002-003	Auxiliary Fuel System Instl. For Bell Model 212 with Single Refueling Port Provisions
41228-000-002-004	Auxiliary Fuel System Instl. For Bell Models 205A/A1 with Single Refueling Port Provisions
41228-000-002-005	Auxiliary Fuel System Instl. For Bell Model UH-1H Huey (army) with Single Refueling Port Provisions
41228-000-002-006	Auxiliary Fuel System Instl. For Bell Models 205A/A1, 212, and 412 (S/N 33001-33107) with Multiple Refueling Port Provisions
41228-000-002-007	Auxiliary Fuel System Instl. For Bell Model 412 (S/N 33108 & Sub.) with Multiple Refueling Port Provisions

PROPRIETARY RIGHTS NOTICE					UNLESS	DRFTSMN	J. MA	RTIN	1/8/96	TITLE				
THESE DATA ARE PROPRIETARY TO ERA AVIATION, INC. DISCLOSURE, REPRO-					OTHERWISE SPECIFIED X.±.1 XX.±.03	CHECK STRESS	P. SCH 96. 96. 96.	WARTZ 014 014 014	3/21/96 3/21/96 3/21/96	TOF	P ASS	EMBLY	DRAWIN	NG
DUCTION, OR USE OF THESE DATA FOR ANY PURPOSE IS FOREID— DEN WITHOUT WRITTEN					XXX.±.010	PROJ. ENGR.			-, -, -	DWG. SIZE	С	SCALE	NONE	
AUTHORIZATION FROM					ANGLES ±.1/2	HEAT TREAT		_				DWG. NO.		REV.
ERA AVIATION, INC. THE FOREGOING DOES NOT APPLY TO VENDOR PARTS.	DASH NO.	PER ASSY	NEXT ASSEMBLY	FD.		FINISH		Era	Avia	tion,	Inc.	41228- SHT	-000-002 1 OF 3	B

BELL 412 S/N 33001-33107	BELL 412 S/N 33108 & SUB	BELL 212	BELL 205A-A1		
41228-000-004	41228-000-004	41228-000-004	41228-000-004		
FUEL TANK INSTALLATION	FUEL TANK INSTALLATION	FUEL TANK INSTALLATION	FUEL TANK INSTALLATION		
41228-200-005	41228-200-005	41228-200-005	41228-200-005		
TANK ASSY	TANK ASSY	TANK ASSY	TANK ASSY		
41228-300-006	41228-300-007	41228-300-006	41228-300-006		
FUEL SYSTEM INSTALLATION	FUEL SYSTEM INSTALLATION	FUEL SYSTEM INSTALLATION	FUEL SYSTEM INSTALLATION		
20528-301-008	20528-301-008	20528-301-008	20528-301-008		
GROUND RECEPTACLE INSTALLATION	GROUND RECEPTACLE INSTALLATION	GROUND RECEPTACLE INSTALLATION	GROUND RECEPTACLE INSTALLATION		
41228-301-064	41228-301-064	41228-301-064	41228-301-064		
CROSS FEED INSTALLATION	CROSS FEED INSTALLATION	CROSS FEED INSTALLATION	CROSS FEED INSTALLATION		
41228-301-066	41228-301-066	41228-301-066	41228-301-066		
FUEL RETURN CAVITY INSTALLATION	FUEL RETURN CAVITY INSTALLATION	FUEL RETURN CAVITY INSTALLATION	FUEL RETURN CAVITY INSTALLATION		
41228-301-068 INSTALLATION FUEL VALVE MOUNTING PLATE		41228-301-068 INSTALLATION FUEL VALVE MOUNTING PLATE	41228-301-068 INSTALLATION FUEL VALVE MOUNTING PLATE		
41228-303-001 (A) INSTALLATION, FLOAT SYSTEM MODIFICATION	41228-303-001 (A) INSTALLATION, FLOAT SYSTEM MODIFICATION				
41228-305-005	41228-305-005	41228-305-005	41228-305-005		
INSTALLATION AFT LUG CAVITY	INSTALLATION AFT LUG CAVITY	INSTALLATION AFT LUG CAVITY	INSTALLATION AFT LUG CAVITY		
41228-400-007	41228-400-007	41228-400-007	41228-400-007		
AUX FUEL AIRFRAME WIRE ROUTING	AUX FUEL AIRFRAME WIRE ROUTING	AUX FUEL AIRFRAME WIRE ROUTING	AUX FUEL AIRFRAME WIRE ROUTING		
41228-401-004	41228-401-004	41228-401-004	41228-401-004		
AUX FUEL ELECTRICAL DIAGRAM	AUX FUEL ELECTRICAL DIAGRAM	AUX FUEL ELECTRICAL DIAGRAM	AUX FUEL ELECTRICAL DIAGRAM		
41228-401-005	41228-401-005	41228-401-005	41228-401-006		
412/212 AUX FUEL ELECTRICAL DIAGRAM	412/212 AUX FUEL ELECTRICAL DIAGRAM	412/212 AUX FUEL ELECTRICAL DIAGRAM	205A/A1 AUX FUEL ELECTRICAL DIAGRAM		
41228-500-003	41228-500-003	41228-500-003	41228-500-003		
INSTALLATION OVERHEAD CIRCUIT	INSTALLATION OVERHEAD CIRCUIT	INSTALLATION OVERHEAD CIRCUIT	INSTALLATION OVERHEAD CIRCUIT		
BREAKER PANEL ASSY	BREAKER PANEL ASSY	BREAKER PANEL ASSY	BREAKER PANEL ASSY		
41228-502-026	41228-502-026	41228-502-026	41228-502-026		
INSTALLATION DUAL BEAD	INSTALLATION DUAL BEAD	INSTALLATION DUAL BEAD	INSTALLATION DUAL BEAD		
SENSOR/IMPACT SWITCH	SENSOR/IMPACT SWITCH	SENSOR/IMPACT SWITCH	SENSOR/IMPACT SWITCH		
41228-600-009	41228-600-009	41228-600-009	41228-600-009		
CONTROL PANEL INSTALLATION	CONTROL PANEL INSTALLATION	CONTROL PANEL INSTALLATION	CONTROL PANEL INSTALLATION		
41228-820	41228-820	41228-820	41228-820		
ROTOCRAFT FLIGHT MANUAL	ROTOCRAFT FLIGHT MANUAL	ROTOCRAFT FLIGHT MANUAL	ROTOCRAFT FLIGHT MANUAL		
SUPPLEMENT	SUPPLEMENT	SUPPLEMENT	SUPPLEMENT		
41228-38	41228-39	41228-38	41228-38 INSTALLATION INSTRUCTIONS		
INSTALLATION INSTRUCTIONS	INSTALLATION INSTRUCTIONS	INSTALLATION INSTRUCTIONS			
41228-43 MANTENANCE INSTRUCTIONS	41228-43 MANTENANCE INSTRUCTIONS	41228-43 MANTENANCE INSTRUCTIONS	41228-43 MANTENANCE INSTRUCTIONS		
41228-46	41228-46	41228-46	41228-46		
ILLUSTRATED PARTS LIST	ILLUSTRATED PARTS LIST	ILLUSTRATED PARTS LIST	ILLUSTRATED PARTS LIST		

-001 LIST

-002 LIST

-003 LIST

-004 LIST

P
BELL UH-1H
41228-000-003 FUEL TANK INSTALLATION
41228-200-004 TANK ASSY
41228-202-131 INSTALLATION CONNECTOR CAVITY
41228-300-003 FUEL SYSTEM INSTALLATION
41228-300-004 FUEL LINE CAVITY INSTALLATION
20528-301-008 GROUND RECEPTACLE INSTALLATION
41228-301-009 STENCIL INSTALLATION SYSTEM CAPACITY
41228-301-037 INSTL. SHUT OFF VALVE MOUNTING BRACKET
20528-301-041 DOUBLER MAIN BEAM
20528-301-043 INSTALLATION CROSS FEED
41228-305-005 INSTALLATION AFT LUG CAVITY
41228-400-007 AUX FUEL AIRFRAME WIRE ROUTING
41228-401-004 AUX FUEL ELECTRICAL DIAGRAM
41228-401-006 205A-A1 AUX FUEL ELECTRICAL DIAGRAM
20528-500-004 INSTL. OVERHEAD CIRCUIT BREAKER PANEL ASSY
41228-502-023 INSTALLATION DUAL BEAD SENSOR
41228-600-009 INSTALLATION CONTROL PANEL
1-1560-311-10 OPERATORS MANUAL
1-1520-210-50-31 INSTALLATION INSTRUCTIONS (MWO)
TMI-1560-311-23 & P MAINTENANCE INSTRUCTIONS & ILLUSTRATED PARTS LIST

BELL 412 S/N 33001 THRU 33107 BELL 212, BELL 205A-A1	BELL 412 S/N 33108 & SUB (EP)
41228-000-004	41228-000-004
FUEL TANK INSTALLATION	FUEL TANK INSTALLATION
41228-200-006	41228-200-006
TANK ASSY	TANK ASSY
41228-300-008	41228-300-009
FUEL RETURN SYSTEM INSTALLATION	FUEL RETURN SYSTEM INSTALLATION
20528-301-008	20528-301-008
GROUND RECEPTACLE INSTALLATION	GROUND RECEPTACLE INSTALLATION
41228-301-066	41228-301-066
FUEL RETURN CAVITY INSTALLATION	FUEL RETURN CAVITY INSTALLATION
41228-301-068	41228-301-068
INSTL. FUEL (BLOCK) MOUNTING PLATE	INSTL. FUEL (BLOCK) MOUNTING PLATE
41228-303-001	41228-303-001
INSTL., FLOAT SYSTEM MODIFICATION	INSTL., FLOAT SYSTEM MODIFICATION
41228-305-005	41228-305-005
INSTALLATION AFT LUG CAVITY	INSTALLATION AFT LUG CAVITY
41228-400-007	41228-400-007
AUX FUEL AIRFRAME WIRE ROUTING	AUX FUEL AIRFRAME WIRE ROUTING
41228-401-004	41228-401-004
AUX FUEL ELECTRICAL DIAGRAM	AUX FUEL ELECTRICAL DIAGRAM
41228-401-005	41228-401-005
412/212 AUX FUEL ELECTRICAL DIAGRAM	412/212 AUX FUEL ELECTRICAL DIAGRAM
41228-500-003	41228-500-003
INSTL. OVERHEAD CIRCUIT BREAKER PANEL ASSY	INSTL. OVERHEAD CIRCUIT BREAKER PANEL ASSY
41228-502-026	41228-502-026
INSTL. DUAL BEAD SENSOR/IMPACT SWITCH	INSTL. DUAL BEAD SENSOR/IMPACT SWITCH
41228-600-009	41228-600-009
CONTROL PANEL INSTALLATION	CONTROL PANEL INSTALLATION
41228-823	41228-823
ROTOCRAFT FLIGHT MANUAL SUPPLEMENT	ROTOCRAFT FLIGHT MANUAL SUPPLEMENT
41228-38 INSTALLATION INSTRUCTIONS	41228-39 INSTALLATION INSTRUCTIONS
41228-43 MAINTENANCE INSTRUCTIONS	41228-43 MAINTENANCE INSTRUCTIONS
41228-46	41228-46
ILLUSTRATED PARTS LIST	ILLUSTRATED PARTS LIST
006 LIST @	007 LIST

-005 LIST

-006 LIST ®

-007 LIST $^{\circ}$

PROPRIETARY RIGHTS NOTICE
THESE DATA ARE PROPRIETARY TO ERA AVIATION, INC.
DISCLOSURE, REPRODUCTION, OR USE OF THESE DATA
FOR ANY PURPOSE IS FORBIDED WITHOUT WRITTEN
AUTHORIZATION FROM ETA AVIATION, INC. THE FOREGOING DOES NOT APPLY TO VENDOR PARTS.

TOP ASSEMBLY DRAWING

TOP ASSEMBLY DRAWING

TOP ASSEMBLY DRAWING

TOP ASSEMBLY DRAWING

TOP ASSEMBLY DRAWING